



INSTRUCTION & INFORMATION

STANDARD TACK APPLICATION TAPE

XP3076 50cm wide x 25m . XP3077 75cm wide x 25m

Our standard application tape has a low/medium tack and made for thermal transfer of printed textile films.

50cm & 75cm samples are available free of charge upon request.

STEP BY STEP

STEP 1

Print and cut design on the printable material. Once cut, weed away the excess material around the design.

STEP 2

Cut a piece of application tape slightly bigger than your design, peel the backing and carefully lay on top of the transfer.

STEP 3

Using a squeegee with pressure, flatten the application tape down and smooth out any bubbles.

STEP 4

Flip over the transfer and application sheet (now stuck together), and peel the backing off the printable media. Now only the weeded design should remain on the application tape.

STEP 5

Position the design onto the garment sticky side down (the sticky backing will aid the placement). Cover with a silicone sheet and press using the recommended settings.

COMPATIBILITY CHART

EVOLUTION PRINT

SUPERFLEX PRINT

EASY PRINT

SUBLI BLOCK

NYLO PRINT

COLOUR CUT

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Standard Tack Application Tape be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. .



Web: www.xpres.co.uk Support www.xprestechnical.co.uk

Oakridge Park, Trent Lane, Castle Donington, Derby DE74 2PY Phone: 01332 855 085 E-mail: sales@xpres.co.uk