xpres INSTRUCTION & INFORMATION

CLASSIC + UNIVERSAL

XP3414 - A4 sheets · XP3413 - A3 sheets

Classic+ Universal paper is a laser printable textile transfer paper. Specifically developed for full colour transfer application to white or pastel tone textiles only.

A4 samples are available free of charge upon request. Xpres cannot be held responsible for any copier/printer breakages.

STEP BY STEP

STEP 1

Print the design using the recommended settings on the plain side of the Classic + Universal paper.

STEP 2

Trim away any excess material.

STEP 3


Position the transfer face down on the garment, cover with a silicone sheet and press at 200 degrees with heavy pressure for 10-15 seconds.

STEP 4

Peel immediately ensuring the garment stays on the bottom plate of the heat press until the paper has been fully removed.

STEP 5

Re-cover the transfer with a silicone sheet and repress for a further 10 seconds. For a softer touch, stretch the garment after pressing,





PRINT SETTINGS

PAPER MODE:	Plain Paper / Heavy
IMAGE MODE:	Mirror Image
FEEDING:	Multi Purpose Tray

SUITABLE FOR	
COTTON	
POLYESTER	
POLYESTER/COTTON (uncoated garment only)	
MOUSE MATS	

TRANSFER SETTINGS		
ТІМЕ	10-15 seconds + 10 seconds (Mouse mats: 3 seconds + 10 seconds)	
ТЕМР	200°C	
PRESSURE	Heavy	
PEEL	Immediately	

CARE INFORMATION	
WASH UP TO 40°C	

DO NOT TUMBLE DRY DO NOT DRY CLEAN CAN BE IRONED INSIDE OUT

PLEASE NOTE: The sellers and manufacturers maximum obligation shall be to replace any product that has been proven to be defective. Neither the seller nor the manufacturer of Classic + Universal shall be liable for any injury direct or consequential, arising out of the use of, or inability to use this range. Classic + Universal has been tested using Kustom Kit garments, use on other garment brands can not be guaranteed and should be tested prior to purchasing this material.

